

Sno-Kone Machines



Operating

- (1) Start the motor and fill the gooseneck an inch from the top with ice cubes or 3" x 4" pieces on ice (the larger the ice pieces, the better the snow).
- (2) Push ice down against the cutterhead with firm pressure for best snow (too much = coarse ice; too little = mushy).

Do not force the handle!

Put only ice in the gooseneck to prevent damage to the blades!

Keep fingers away from shaver body when motor is running to prevent injury!

A surface temperature of 150°F is normal.

Cleaning

- (1) Unplug the machine.
- (2) Wipe all surfaces with a clean cloth.
- (3) Pump warm water through syrup pumps.